



Pos No	Part #	Description	Pos No	Part #	Description
01-2	202868	Bottom Plate	27	201684	Power Cable w/ Gland - 230V, 1 PH, No Plug
5	202114	Impeller Vortex	27-1	203191	O-Ring (Kit Only)
7	202185	Pump Housing w/ Bottom Plate	31E	203145	Ground Wire w/Ring Term.
07-1	203191	O-Ring (Kit Only)	32	203161	Power Cord Line Clip
8	202207	Oil Chamber Cover	34	202517	Handle
08-1	203191	O-Ring (Kit Only)	35	202665	Holding Rods
9	202229	Lip Seal Buna-N	38	202531	Disch. Nipple NPT Cast Iron 2"
10	202258	Shaft Sleeve	38F	202569	Discharge Flange 2", 45°
13	202259	Mechanical Seal Buna-N	38F	202562	Discharge Flange
13	202260	Mechanical Seal FKM**	38F-1	203206	Gasket -Discharge Flange Buna-N
14	200493	Lower Ball Bearing	50-01-2	203216	Screw for Power Cord
17	202302	Rotor w/ Shaft 115/230V, 1PH	50-07	203238	Bolt - Strainer/Stand
18	200511	Stator Coil w/ Casing 115, 1PH	50-08	203215	Screw for Oil Chamber Cover
18	200521	Stator w/Casing, 230V, 1PH	50-11	203218	Screw for Oil Fill
19	202359	Governor Switch w/Switch Plate	50-11-1	203191	O-Ring (Kit Only)
20	200957	Lower Ball Bearing	50-12	203218	Screw for Oil Fill
21A	200498	Oil Chamber	50-12-1	203191	O-Ring (Kit Only)
21A-1	203191	O-Ring (Kit Only)	50-19	202693	Screw for Gov. Switch Plate
21B	202365	Motor Cover	50-19B	203215	Screw for Oil Chamber Cover
22	202380	Cover Plate Upper	50-22	203214	Screw
24	202415	Capacitor 115V	50-27	203295	Screw for Seal Minder Cable
24	202416	Capacitor 230V	50-31E	202692	Screw for Ground Wire
26	203120	Pump Top Cover	50-32	203214	Screw
26-1	203191	O-Ring (Kit Only)	50-34	203219	Screw for Oil Chamber Cover
27	204257	Power Cable w/ Gland - 115V, 1 PH	50-38F	203230	Bolt - Discharge Flange